

Item Code	Model	Application	Cutting Length	Blade Thickness	Kerf	Tooth Spacing	Overall Length	Replacement Blade,	
								Item Code	Model
15075	III 265	Medium-Fine	265mm (10-1/2")	0.60mm (0.024")	0.92mm(0.037")	1.75mm (15TPI)	597mm (23 -1/2")	15076	III 265 B

Hook Style, Efficient Interchangeable Blade System

Why is Z-Saw blade not necessary to be re-sharpened?

If you saw with conventional style handsaws, you have to spend your working time to re-sharpen the teeth. It is a time taking and awkward job, indeed? And, in spite of your effort, the blade never becomes as sharp as brand-new blade if re-sharpening is made by hand. Z-Saws release you from troublesome blade re-sharpening! The teeth of Z-Saw are impulse hardened which provides much longer life than conventional saw blades. All Z-Saw blades are replaceable very easily and quickly. Z-Saws make you concentrate on sawing.





How to detach blade Always swathe blade in a towel and wear gloves. Tap gently the back of the handleend.



How to replace blade

Always swathe blade in a towel and wear gloves. Insert and hook spare blade on the holder in the direction of arrow. Tap the handle end lightly.